

Software is in zipped file:

Model Fx\_V1.15.zip

Unzip the file to a location/folder of your choice on your computer. Go to this folder. There should be a directory called 'Image' in the unzipped folder.

Connect the Model Fx to a computer running Windows, using the USB port on the back of the instrument.

Switch on the Model Fx, the computer should see a removeable drive/directory/folder appear if Autoplay is enabled. Otherwise you may need to start Windows explorer and find it.

If there is a folder called 'Image' on the Model Fx drive, delete it and its contents.

Copy the new unzipped 'Image' folder (and contents) to the Model Fx removeable drive.

Turn the Model Fx instrument off. Disconnect the USB cable to the computer.

Press and hold down the lefthand button of the five buttons under the Model Fx instrument display. Whilst holding this button down, turn the instrument on. When the screen turns white release the buttons. The instrument upgrade will display its progress, and will take approximately 20 minutes, after which the instrument will switch off.

Turn the Model Fx back on normally and the instrument will be using the upgraded software.